



XP5s – How to Initiate a Linc PTT (WAVE) Call


Follow these steps to initiate a Linc PTT call on the XP5s during the transitional period



From LincAssist, point the toggle button towards Linc PTT



From the Apps Screen, open Linc PTT




Choose/Select the PTT contact

XP5s – How to Initiate a Linc PTT (WAVE) Call



Select the Back button to put the Linc PTT app in the background



Push the PTT button to initiate the call